


CATEGORY


POS
Godex DT4X

GODEX DT4X PRINTER SETUP


- Connect ethernet cable and power to Godex DT4X printer
- Download driver and install
<https://www.seagullscientific.com/downloads/printer-drivers/godex-dt4x/>
- Goto Control panel (search from your windows computer)
- Open Devices and printers
- Right Click on Godex DT4X printer and choose "printing preference"



- Click Edit and change it to 2 x 1



- Click OK and save
- Download and install GoUtility



PUREJOIN

PROFESSION OR INDUSTRY | LINK TO OTHER ONLINE PROPERTIES: PORTFOLIO/WEBSITE/BLOG

- <https://www.godexintl.com/product/15820156824815981?ocale=en>
- Click Search

	AliasName	IP	Port	MAC	Model	FW Version	Status	S
1	DT4xW	192.168.38.211	9100	00-1D-9A-07-5D-4C	DT4xW	V2.00A(Aug 19 2019)	00	
▶ 2	DT4xW	192.168.38.90	9100	00-1D-9A-08-40-12	DT4xW	V2.100 (May 07 2020)	00	

-
- Get the IP address and enter it to your Purejoin Inventory App



EMAIL




TWITTER HANDLE



TELEPHONE



LINKEDIN URL



PUREJOIN

PROFESSION OR INDUSTRY | LINK TO OTHER ONLINE
PROPERTIES: PORTFOLIO/WEBSITE/BLOG



EMAIL



TWITTER HANDLE



TELEPHONE



LINKEDIN URL